



# TECHNICAL DATA SHEET

**Product Name:** PowerBond Anti-Curling Non Slip Reusable Rug Gripper

**Product Features:**

**Size:** 4 Pack Large Triangle Shapes

**Temperature Resistance:** -16°C or above 120°C

**Colour:** Black

**Material:** High-quality, Non-Toxic & Safe, Easy To Use

- Grip Rugs So That They Do Not Slip
- Prevent Curled Corners, Bunches, Slips & Trips
- Won't Leave a Sticky Residue Or Damage Your Floor
- Multipurpose Gripper (Secure Objects from Moving)
- Tacky Grip Polymer Technology Grips The Rug, While Hundreds Of Suction Pockets Grip The Floor
- Reusable, Sustainable

**Product Benefits:**

- Keeps rugs securely in place, preventing slipping, curling, bunching, and tripping hazards
- Suitable for all types of hard floor surfaces
- Easy to use, simply press and stick
- Reusable and sustainable - can be washed and reused time and time again
- Non-toxic and safe for use in homes with pets and children
- Won't damage your floors - leaves no sticky residue
- Multipurpose gripper can be used to secure other objects from moving

**Instructions for Use:**

1. Clean the surface of the floor where the rug will be placed, and make sure it is dry and free from dust and debris.
2. Peel off the backing from the reusable rug gripper.
3. Stick the gripper onto the underside of the rug, positioning it at each corner and along each edge as necessary.
4. Press down firmly to ensure a secure grip.
5. Place the rug back onto the floor, and enjoy a stable, non-slip surface.

**To Re-Use:**

1. Remove the rug from the floor and gently peel off the grippers.
2. Wash the grippers in cool water, removing any dust and dirt.
3. Dry the grippers with a hair dryer, or leave to air dry.
4. Reapply the grippers to the rug and place it back onto the floor.